

RiteWay Crack Repair

Installation Guidelines

1. Crack must be free of dirt & debris.
2. Crack must be filled from bottom to top with court patch binder or cement and let dry.
3. Filled Crack must be scraped or buffed flush with court and cleaned, broomed and blown.
4. Area to be repaired must be DRY and at 60°F or higher.
5. First layer is to be centered over Crack by removing a few inches of the release liner exposing the soft sealant apply to Crack when centered, pull release liner to move along Crack. If Crack turns cut tape and butt up another piece and continue. Make sure there are no bubbles. If a bubble is found cut with razor knife and press out bubble. Roll with tape machine pressing firmly.
6. Apply Liquid Acrylic over tape with paint roller approximately 24” wide. Apply 20” stress mat centered over first layer making sure there are no wrinkles, etc. Using roller saturate stress mat with liquid acrylic, making sure there are no bubbles and roll smooth.
7. Apply bonding edge ½ on fabric ½ on court and roll on Liquid Acrylic making sure there are no wrinkles or bubbles and let dry.
8. When totally dry squeegee resurfacer with sand lengthwise over crack this will fill voids where layers overlap and hide the repair. Minimum of two coats are recommended.

Repair is complete.